




HOW TO SET UP YOUR GRIZZL-E CHARGER WITH AMPUP

Connect Grizzl-E to Wi-Fi

- Step 1:** Open the Wi-Fi Settings on your phone or desktop. Select the network **UC_Smart_[ChargerSerial#]**
- Step 2:** Open your browser page. Type in the IP address **192.168.4.1**.
- Step 3:** A webpage will load. Select the **Enter Router Credentials** button.
- Step 4:** Enter your router's SSID and password.
- Step 5:** Enter the following URL into the Portal URL field:

[centralsystem.ampup.io/ocpp/united-chargers/\[ChargerSerial#\]](https://centralsystem.ampup.io/ocpp/united-chargers/[ChargerSerial#])


- Step 6:** Select the **Enter Credentials** button.
- Step 7:** Verify that you are connected. If connection is successful the indicator light will alternate between Blue and Light Blue.



ADD YOUR CHARGER TO AMPUP

Download the AmpUp app on the App Store or Play Store.


Add your charger, manage settings, and share!






Set Up Charger on AmpUp

Step 1: From the home screen/login screen, select the profile icon in the top left.




Step 2: Select the settings tab above your name.



Step 3: Select the **My Home Charger** field.

Step 4: Select the **Add Charger** button.



Step 5: Select Grizzl-E from the Charger Brand drop down list. Confirm that you have configured your Grizzl-E Charger.

Step 6: Enter the Charger Serial Number in the **Charger ID** field.

Step 7: Fill any other optional information about the charger.

